

2019 Corvette ZR1 and Z06: PDI - Corvette ZR1 and Z06 Wide Brake Cooling Deflector Installation

Reference Number: GCUS-9-5723

PDI - Corvette ZR1 Wide Brake Cooling Deflector Installation

GM CUSTOMER CARE & AFTERSALES

URGENT - DISTRIBUTE IMMEDIATELY

DATE	March 27, 2018
SUBJECT	PDI - Corvette ZR1 and Z06 Wide Brake Cooling Deflector Installation
MODELS	2019 Chevrolet Corvette ZR1 and Z06
TO	All Chevrolet Dealers
ATTN	Service Manager, Shop Foreman

This message is being resent to include the Corvette Z06

**** Please share this information with technicians ****

The wide brake deflectors (loose items shipped with the car) will not fit due to an interference with the brake duct. The wide deflectors should not be installed.

DO NOT modify the brake duct to make the wide deflector fit.

The short deflector should be installed at the time of PDI and no change is required for track use.

Bulletin 16-NA-363 is being revised to reflect this information.

Online URL: <https://www.corvetteactioncenter.com/tech/knowledgebase/article.php?id=1390>