

# 1981 Corvette: ECM Codes

---

Code #12: No Distributor Reference Pulse.  
Code #13: Oxygen Sensor Circuit.  
Code #14: Shorted Coolant Sensor Circuit.  
Code #15: Open Coolant Sensor Circuit.  
Code #21: Throttle Position Sensor Circuit.  
Code #23: Mixture Control Solenoid Circuit.  
Code #24: Vehicle Speed Sensor Circuit.  
Code #32: Baro Sensor Circuit Low.  
Code #34: Vacuum Map Sensor Circuit.  
Code #44: Oxygen Sensor Lean.  
Code #45: Oxygen Sensor Rich.  
Code #51: Faulty or Mis-Installed PROM.  
Code #52: Faulty ECM.  
Code #53: Faulty ECM.  
Code #54: Shorted Mixture Control Solenoid.  
Code #55: Faulty Oxygen Sensor or ECM.

Online URL: <https://www.corvetteactioncenter.com/tech/knowledgebase/article.php?id=693>