

# 2019 Corvette ZR1 and Z06: PDI - Corvette ZR1 and Z06 Wide Brake Cooling Deflector Installation

Reference Number: GCUS-9-5723

PDI - Corvette ZR1 Wide Brake Cooling Deflector Installation

**GM CUSTOMER CARE & AFTERSALES**

**URGENT - DISTRIBUTE IMMEDIATELY**

DATE	March 27, 2018
SUBJECT	PDI - Corvette ZR1 and Z06 Wide Brake Cooling Deflector Installation
MODELS	2019 Chevrolet <b>Corvette ZR1 and Z06</b>
TO	All Chevrolet Dealers
ATTN	Service Manager, Shop Foreman

**This message is being resent to include the Corvette Z06**

**\*\* Please share this information with technicians \*\***

**The wide brake deflectors (loose items shipped with the car) will not fit due to an interference with the brake duct. The wide deflectors should not be installed.**

**DO NOT modify the brake duct to make the wide deflector fit.**

**The short deflector should be installed at the time of PDI and no change is required for track use.**

**Bulletin 16-NA-363 is being revised to reflect this information.**

Online URL: <https://www.corvetteactioncenter.com/tech/knowledgebase/article/2019-corvette-zr1-and-z06-pdi-corvette-zr1-and-z06-wide-brake-cooling-deflector-installation-1390.html>

