

# 1984 Corvette: Service Bulletin: Dealer Installed Anchor for Child Seat with Top Strap Anchor Installation

**Subject:** Dealer Installed Anchor for Child Seat with Top Strap Anchor Installation

**Model and Year:** 1984 Corvette

**Source:** Chevrolet Dealer Service Technical Bulletin

**Bulletin No:** 84-121

**Section:** 10 (I)

**Date:** May 1984

TO: ALL CHEVROLET DEALERS

Should a customer request the installation of a child seat top tether anchor, in their 1984 Corvette, the following installation steps are to be performed:

1. Remove rear floor carpet and insulator.
2. Drill a 9mm (11/32 inch) diameter hole through the front at the location shown in Figure #1. **CAUTION:** Double check hole location to avoid damage to the vehicle under-carriage components.
3. Reinstall insulator, cut 38mm (1 1/2 inch) diameter hole for washer/spacer\*. Reinstall the carpet and cut a 9mm (11/32 inch) diameter hole for the anchor attachment bolt.
4. Using a suitable sealer, such as silicone or butyl type caulking, apply a bead of sealant around the 9mm (11/32 inch) drilled hole in the floor pan. **NOTICE:** The sealant is to be applied on the outer side of the floor pan (see Figure #2).
5. Install the tether anchor bracket, as shown in Figure #2, and tighten nut securely. **NOTICE:** In the event the tether anchor assembly is removed, the 9mm diameter hole must be properly resealed to prevent exhaust fumes from entering the vehicle.

\* Washer/spacers (not supplied):

Three (3) flat washers 32 mm (1 1/4 inch) x 3mm (1/8 inch) thick, with a 9mm (11/32 inch) diameter hole. Total stack-up of washer/spacer is to be 9.5mm (3/8 inch).

Chevrolet Motor Division  
General Motors Corporation

Online URL: <https://www.corvetteactioncenter.com/tech/knowledgebase/article/1984-corvette-service-bulletin-dealer-installed-anchor-for-child-seat-with-top-strap-anchor-installation-945.html>