## 2020 Corvette: Service Bulletin: #20-NA-042: Fuel Gauge May Intermittently Display Erratic and/or Empty Readings, Malfunction Indicator Lamp (MIL) Illuminated - DTC P0462 Set

#20-NA-042: Fuel Gauge May Intermittently Display Erratic and/or Empty Readings, Malfunction Indicator Lamp (MIL) Illuminated - DTC P0462 Set - (Oct 19, 2020)

Subject: Fuel Gauge May Intermittently Display Erratic and/or Emp

Malfunction Indicator Lamp (MIL) Illuminated - DTC P04

Brand: Mode	l: Model Year	: VIN:	Engine: Transmi
	from to	from to	ssion:
Chevrol Corve	tt 2020 20	20 SOP L510 51	001 6.2L — (RPO LT2)

**Involved Region or Country** 

**Condition** 

North America, Middle East

Some customers may comment on one or more of the following conditions:

- Fuel gauge intermittently displays erratic and/or empty readings
- MIL illuminated

Some technicians may find DTC P0462 (Fuel Level Sensor 1 Circuit Low Voltage) displayed in the Engine

Control Module (ECM).

Cause This condition may be caused by

erratic fuel value readings sent from

the left fuel tank level sensor.

Correction If the customer concern has been

verified, replace the left side fuel

tank level sensor.

## **Service Procedure**

Refer to Fuel Level Sensor Replacement in SI.

## **Parts Information**

Causal Part	Description	Part Number	Qty
X	SENSOR KIT,	84745186	1
	FUEL LVL		

Version 2

Modified Released March 09, 2020

October 19, 2020 – Added a VIN breakpoint and changed the Warranty

Information.

## Online URL:

https://www.corvetteactioncenter.com/tech/knowledgebase/article/2020-corve

tte-service-bulletin-20-na-042-fuel-gauge-may-intermittently-display-erratic-a nd-or-empty-readings-malfunction-indicator-lamp-mil-illuminated-dtc-p0462-set-1462.html